

These flex plate-to-converter bolts have thicker heads for better wrenchability. In some cases, the head may contact the block. Check for clearance before completing the job. .040" clearance is adequate. Do not use any washers. Be sure and use a thread-locking compound on the threads, such as Red Loctite #271.