



Typical spacer & shim placement for SB Edelbrock RPM head w/ .350" offset rockers.

Not all heads are exactly the same